



Personal Protective Equipment Donning



1. Remove jewelry, use bathroom, check in with safety officer
2. Select Tyvek suit that fits (though loosely, be able to squat / bend easily)
3. Put on suit, zip front, peel adhesive and seal
4. Adjust fit with tape, including crotch and front if needed
5. Put on boots and pull pants down over top, tape leaving tab
6. Put on inner nitrile gloves – no tape!
7. Open respirator canister packs, remove caps and screw 3 filters onto unit
8. Turn dial on battery pack top to turn on
9. Put on hood and tuck inner hood into suit
10. Put on outer butyl gloves over fist, pull suit cuff over glove and tape to suit
11. Enter warm zone

Personal Protective Equipment Removal



1. Position self close to warm/cold line
2. Remove respirator, clean as directed or place in bag and leave in room
3. Open and unzip front
4. Pull arm through suit, leaving glove behind
5. Work free hand down inside of other sleeve to free other arm
6. Work hands down inside of suit to free legs / ankles
7. Step out of suit and across into cold zone
8. Check in with Safety Officer



Hennepin County **Medical Center**

Call Hennepin Connect:
612-873-4262 or 1-800-424-4262